



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAYS 16L/R: Maintain runway heading until 600', then turn left to a 120° heading to intercept and proceed via the SAC R-058 to DUDES INT, then via (transition) or (assigned route). Expect further clearance to filed altitude after CROTI INT.

TAKE-OFF RUNWAYS 34L/R: Maintain runway heading until 1500', then turn right to a 140° heading to intercept and proceed via the MYV R-154 to LIAMM INT, then turn left to a 090° heading to intercept and proceed via the SAC R-058 to DUDES INT, then via (transition) or (assigned route). Expect further clearance to filed altitude after CROTI INT.

LOST COMMUNICATIONS: Take-off runways 34L/R: Maintain runway heading until 1500', then turn right heading 140° to intercept and proceed via the MYV R-154 to intercept and proceed via the SAC R-058 to DUDES INT. Then resume own navigation.

LOVELOCK TRANSITION (DUDES9.LLC): From over DUDES INT via the SAC R-058 and the LLC R-198 to LLC VORTAC.

MINA TRANSITION (DUDES9.MVA): From over DUDES INT via the MVA R-257 to MVA VORTAC.

MUSTANG TRANSITION (DUDES9.FMG): From over DUDES INT via the FMG R-192 to FMG VORTAC.

SW-2, 03 JUL 2008 to 31 JUL 2008

SW-2, 03 JUL 2008 to 31 JUL 2008